

EZ PURGE[®]

INTRODUCING

Pre-Formed, Self-Adhesive, Water-Soluble Purge Dams

Revolutionizing the Way TIC Purging is Done

EZ to use as 1-2-3!



1 Peel liner to expose adhesive



2 Insert EZ Purge[®] dam inside pipe



3 Press tape along circumference of pipe wall

Your purge dam is complete in less than a minute!

- Ready to use
- Cut labor costs
- Gets you ahead of schedule

US Patent Granted & Foreign Patents Pending.



Aquasol
CORPORATION

Aquasol Makes Purging as EZ as 1... 2... 3!



1

*Pure welds start with preparation.
Clean pipe with EZ Wipes™.*

EZ Wipes™ are multi-purpose, saturated abrasive cleaning wipes that remove oil, grease, marker and more from pipe surfaces where contamination can severely impact the quality of the weld.

2

Insert EZ Purge®

Just peel, insert and press in place!



3

*Position EZ Zone™ Tape
over weld joint*

EZ Zone™ Tape is a purge gas retaining tape used to seal the root gap between pipes and ensure minimal gas loss during purging. Designed with an adhesive-free center zone, the patented EZ Zone™ Tape creates a contaminant free weld.



Aquasol
CORPORATION

For more information, visit us at www.aquasolcorporation.com
or call 1.800.564.WELD (9353)